

Installation Instructions

Models: BSDD

3/16" Framed Double Door



P/N MM.5009 (8-17)

Scan this Bar Code for Parts Bag:



Parts List

Latch Pack CAT#: PART LIST

QTY.:	PART LIST:
2	1. Door Assembly
2	2. 1268 Wall Channel
1	3. 1193 Latch Jamb
1	4. 1020 Stall Header

Parts Bag #3701

QTY.:	PART LIST:
6	5. 2217 Wall Anchor
6	6. 2101 #8 x 1 1/2 FPHSMS
6	7. 2110 #8 x 1/2 PHPH TEK
2	8. 2102 #6 x 3/8 PHPHSMS
1	9. 4314 Soft Sill

General Required Tools

- * Pencil or water soluble felt pen
- * #2 Phillips Screw driver
- * 4 ft. Level
- * Hacksaw with 24 tooth blade
- * 7/64" and 3/16" drill bits
- * Rubber mallet
- * Metal file (smooth sharp edges)
- * Caulking gun
- * Razor knife
- * Tape measure
- * Clear 100% Silicone (recommended)
- * Blue painters tape
- * Drill, electric or battery