



# 3/16" FRAMED NEO-ANGLE CORNER SHOWER ENCLOSURE



HARDWARE PACK: QTY:

CAT#:	PART LIST:	LENGTH:	QTY:
①	DOOR ASSEMBLY		1
②	PANELS		2
③	1193 STRIKE JAMB & Mag.		1
④	1175 135° CORNER POST		1
⑤	1268 WALL CHANNEL		2
⑥	1171 DOOR STALL HEADER		1
⑦	1171 PANEL STALL HEADER		2
⑧	1171 DOOR STALL CURB		1
⑨	1271 PANEL STALL CURB		2
⑩	1097 DRIP RAIL		1
⑪	1072 CURB FILLER		2




⑫	4018 VW-2 VINYL SWEEP	1
⑬	2018 HEADER PLATE	4
⑭	2017 HEADER CLIP	8
⑮	2204 FOAM PLUG	2
⑯	2203 SETTING BLOCKS	4
⑰	2101 #8X1-1/2" FHPHMS	6
⑱	2217 WALL ANCHORS	6
⑲	2110 #8X1/2" PHPH TEK	6
⑳	2103 #6X3/8" FHPHMS	16
㉑	2102 #6X3/8" PHPHMS	6
㉒	425 VS-13 THIN VINYL	8
㉓	426 VS-14 THICK VINYL	8


## TOOLS REQUIRED FOR P/F/P REV INSTALLATION

1. Caulking gun & approved silicone sealant
2. Rubber Mallet
3. Hacksaw
4. Phillips Screwdriver
5. Mill file to smooth cut edges or radius
6. 3/16" drill bit for plastic anchors
7. 3/16" carbide drill bit for tile
8. C-clamp or strong spring clamp
9. Drill & 1/8" Drill Bit
10. Level

1. The curb sections may have already been cut to size at the factory. If not, measure the centerline distance of the door and return panels on the threshold and add 3/16" to each measurement. Measure from the longest point of the miter and cut the square end of the curb. On the door section add 3/8" and you must duplicate the factory miter at the other end. Insert one foam plug into each square cut end of the return section. Recess about 1/8" and fill recess with sealant. Assemble curb sections with two curb clips and a header plate. With the corners tight, mark the holes in the plate onto the curb, drill with a 1/8" bit and secure the plate to the header with #6x3/8" flat head screws. Position curb sections onto the base. Seal the mitered corners with sealant and readjust alignment if necessary. Insert a setting block into the curb where the glass panels will set, glass should never set on the metal curb.




2. Place the wall channel into the curb, against the wall and plumb with a level. Mark the mounting holes and remove the channel. Drill a 3/16" hole and insert the wall anchors. Use a carbide bit for tile or masonry applications. Secure the channel to the wall with a #8x1-1/2" flat head screw and repeat for the other wall.



3. Insert the correct glass panel for the return into the wall channel and the curb, making sure that it is on setting blocks. If patterned glass or frosted glass is used, make sure that the rough side faces out. Insert the corner post over the edge of the glass and into the curb. Hold the corner post and glass in place temporarily with the thin vinyl on each side of the glass into both of the channels at the top. Do not cut the vinyl at this time. Repeat this procedure for the second panel.

4. Using a level, plumb each of the 135° corner posts. Measure from the outside of the corner post to the wall in each direction. Add 1/16" to each dimension. Cut the appropriate header for each return panel measuring from the longest point and cutting from the square end. Measure from the outside of each corner post for the door header, and add 1/8" to that dimension. Cut the door header to that dimension and duplicate the factory miter on the other end. Assemble the header sections with 2 header clips and 1 header plate. Making sure that the miters are tight, mark the holes in the plate onto the top of the header. Drill the holes with a 1/8" drill bit. Secure the plate onto the headers with 4 #6x3/8" flat head screws.



5. Set headers in place over the top of the vertical posts. From the inside of the shower, attach the headers by drilling through the headers into the verticals with a 1/8" drill bit. Secure with #6x3/8" pan head screws. Make sure to avoid the glass panels while drilling. The bottom of the 135° posts should be secured in the same manner.

6. Center the return panel glass between the wall channel and the corner post, and insert the thin vinyl between the glass and vertical metal channels on both sides. Insert the thick vinyl between the glass and the header and between the glass and the curb, inside and out. Repeat for the other panel.

7. Place the strike jamb (#3) over the vertical post of your choice, do not secure at this time. Orient the door so that it can open outwards and slide it over the remaining post. Adjust the door and strike so that they are equally off of their respective posts. Adjust the hinge jamb so that the top of the door is parallel with the bottom of the header. From the inside of the shower, drill the top hole through the hinge jamb into the vertical post with a 1/8" drill bit. Secure the jamb with a #8x1/2" pan head TEK screw. Recheck door alignment and repeat the procedure for the middle and bottom screws.

8. Adjust the strike jamb to the door assembly. Center the magnets on each other. If the magnets repel each other, remove the strike jamb, and slide the magnet out, turn end for end and insert back into the jamb. Replace the jamb and adjust to work with the magnet on the door. Once adjusted correctly, from the inside of the shower, drill the top hole into the strike jamb and vertical post with a 1/8" drill bit. Secure the jamb with a #8x1/2" pan head TEK screw. Recheck alignment and repeat the procedure for the middle and bottom screws.

9. To install the drip rail at the bottom of the door, measure the frame only, that surrounds the glass. Add 3/8" and cut the drip rail to this size. Radius the end of the drip rail to be similar to the factory end. Install the bottom sweep vinyl into the bottom of the drip rail, and trim with 1/4" extending out of each end of the drip rail. Notch the thick part of the drip vinyl where it meets the strike jamb. Peel the backing off of the drip rail. From the inside of the shower, close the door and install the drip rail so that the vinyl sweep is 1/16" above the dam strip.

10. Run a continuous bead of silicone across the outside of the shower unit where the metal meets the walls and threshold.

**NOTE;** For installation and technical support please reference the shipping document, the box that the product was shipped in or call the store where you purchased this product from.